

4. Remove the unit, and confirm marks are in the correct location

7. Return the unit, and secure in place with screws, and cover screws with cap (A and B).

(12.0" left to right, and 7.0" front to back).

6. Drill 5 holes using the 1/8" drill bit.

5. Mark a center point between the back two holes.

- 5. Remove the unit, and confirm holes are in the correct location (8.0" left to right, and 10.875" top to bottom).
- 6. If mounting to drywall, drill holes with the 1/4" drill bit, and place anchors (C) in the holes
- 7. If mounting to a stud, drill holes with 1/8" drill bit
- 8. Return the unit to the location, and secure in place with screws, and cover screws with cap (D and B).