



• Attach pedestal clamp by turning the c-clamp knob clockwise; adjust the clamp bracket position if necessary with a Phillips screwdriver. Place ring over ball, attach camera bolt adapter over ball, and tighten to set to position.



3 Unscrew lateral screw and insert GoPro HERO (sold separately) to the adapter. Re-insert lateral screw.



## Package Contents:

GN086-SBH - C-Clamp Mounting Pedestal with 4" Adjustable Arm

AP-CMP - 1/4"-20 Camera Bolt Adapter

SP-SB-AMPS-22 - AMPS Swivel Ball Head for 22mm Pedestals

SP-1420-SCREW - 1/4"-20 to GoPro® HERO® Mount Connection Adapter


**NOTE:** C-Clamp Opening: .25" - 2.25" (6mm - 57mm).

## **Device Compatibility:**


Compatible with GoPro® HERO®4, HERO3, HERO3+, HERO2 and HERO action cameras, as well as 1/4"-20 compatible cameras.

GoPro® and HERO® are trademarks or registered trademarks of Woodman Labs, Inc. in the United States and other countries. Arkon Resources, Inc. is not affiliated with Woodman Labs.

2 Screw the included 1/4"-20 to GoPro HERO Adapter onto the mounting bolt.



**OPTIONAL:** Release the GoPro mount by pressing on the release tab.





## **Safety Precautions**

Arkon is not responsible for any damages caused to your device or yourself due to the installation or use of this mount.



The Mobile Mounting Specialists™

Consumer Hotline: USA (800) 841-0884 INT'L (626) 254-9005 Monday - Friday 9am - 5pm, PST

www.arkon.com
Arcadia, CA 91006 USA
Designed in USA | Made in China & Taiwan
© Copyright 2015 Arkon Resources, Inc.