
GPROTRIXL | Flexible 11" Tripod for GoPro[®] HERO[®] Action Cameras





1 Screw ¼"-20 to GoPro adapter onto the tripod's mounting bolt.

Unscrew lateral screw and insert GoPro HERO (sold separately) to the adapter. Re-insert lateral screw.



3 Release the 1/4"-20 mount by unscrewing lateral screw and pressing on release tab.







 Consumer Hotline:

 USA
 (800) 841-0884

 INT'L
 (626) 254-9005

 Monday - Friday 9 am - 5 pm, PST

www.arkon.com Arcadia, CA 91006 USA

Arcadia, CA 91006 USA Designed in USA | Made in China © Copyright 2014 Arkon Resources, Inc.