



MOBILE ENHANCEMENT

World Wide Web
<http://www.samsungmobileusa.com>

Printed in Korea
Code No.:GH68-21225A
NA. 12/2008. Rev. 1.0

SAMSUNG

English / Español



HEADSET

WEP650

MOBILE ENHANCEMENT

English	1
Español	37F

Contents

Getting started

Your headset overview	3
Button functions.....	4
Charging the headset.....	4
Wearing on the headset.....	6

Using your headset

Turning the headset on or off	7
Pairing and connecting the headset.....	8
Using call functions.....	9

Appendix

Frequently asked questions.....	12
Certification and Safety approvals.....	14
UL certified charger	15
Warranty and parts replacement.....	16
Specifications.....	17

Take the time to read through this user's guide before you start to use WEP650 Bluetooth Headset.

Bluetooth® is a registered trademark of the Bluetooth SIG, Inc. worldwide—Bluetooth QD ID: B014732

More information about Bluetooth is available at www.bluetooth.com.



Safety precautions

- Never disassemble or modify your headset for any reason. Doing this may cause the headset to malfunction or become combustible. Bring the headset to an authorised service center to repair it or replace the battery.
- When using your headset while driving, follow local regulations in the country or region you are in.
- Avoid storage at high temperatures (above 50° C/122° F), such as in a hot vehicle or in direct sunlight, as this can damage performance and reduce battery life.
- Do not expose the headset or any of its supplied parts to rain or other liquids.



At very high volumes, prolonged listening to the headset can damage your hearing.

Getting started

This section explains what to remember for the proper use of your Bluetooth headset.

Your headset overview



Make sure you have the following items with your headset :
Charger, User guide.
The items supplied with your headset may vary depending on your region.

Button functions



Talk button

- Press and hold to turn the headset on or off.
- Press to make or answer a call.
- Press to end a call.
- Press and hold to enter Pairing mode

+/- Volume up/down buttons

- Press to adjust the volume.

Charging the headset

This headset has a rechargeable internal battery which is non-removable. Ensure that you fully charge the battery before using the headset for the first time.

- 1 Plug the charger into the charger jack on the headset.
- 2 Plug the charger into a power outlet. During charging, the indicator light will turn red.
- 4 If charging does not begin, unplug the charger and plug it in again.



- 3** When the headset is fully charged, the indicator light changes to blue. Unplug the charger from the power outlet and the headset.



- Use only a Samsung-approved charger. Unauthorized chargers may cause an explosion or damage to the headset.
- The battery will gradually wear out while charging or discharging because it is a consumable part.
- The headset is not able to operate while charging. Try connecting after charging is completed.

When the battery power is low

The headset beeps and the indicator light flashes red. Recharge the battery. If the headset powers off during a call, the call will be automatically transferred to the phone.

Wearing on the headset

Place the headset on your ear. Ensure to put the correct (Left, Right) earpiece on each ear. Your headset has the E-Clip feature which keeps the headset stable on your ear with the adjustable earpiece.



Depending on what ear you are going to wear the headset, simply adjust the ear hook accordingly.



▲ Left



▲ Right

Using your headset

This section explains how to turn the headset on, pair and connect with the phone, and use various functions.



- Activated functions and features may differ depending on the types of your phone.
- Some devices, especially those that are not tested or approved by Bluetooth SIG, may be incompatible with your headset.

Turning the headset on or off

- To turn the headset on, press and hold the talk button until the blue indicator light flashes 4 times.
- To turn the headset off, press and hold the talk button until both blue and red indicator lights flash.

Pairing and connecting the headset

Pairing will create a unique and encrypted wireless link between two Bluetooth enabled devices, such as a Bluetooth phone and a Bluetooth headset. To use the headset with other Bluetooth devices, both devices must be paired. When trying to pair the two devices, keep the headset and the phone reasonably close together. After pairing, you can connect the two devices.

Pairing and connecting the headset with a phone

- 1 Enter Pairing mode.
 - Turn on the headset with pressing and holding the talk button until the indicator light turns blue and stays lit after blinking.
 - When you turn on the headset for the first time, it automatically enters Pairing mode.
- 2 Activate the Bluetooth feature on your phone and search for the headset (see your phone's user guide).
- 3 Select the headset (Samsung WEP650) from the list of devices found by your phone.
- 4 Enter the Bluetooth PIN (0000, 4 zeros) to pair and connect the headset to your phone.

Disconnecting the headset

To disconnect the headset from your phone,

- Turn off the headset
- Use the Bluetooth menu of your phone

Reconnecting the headset

When the headset is paired with a phone, it will attempt to automatically reconnect each time you turn it on.

If the headset does not attempt to automatically reconnect,

- Press the talk button.
- Use the Bluetooth menu of your phone

Using call functions

Making a call

Redialing the last number

Press and hold the talk button to redial the last number.

For some phones, pressing the key opens the call log list. Press the talk button to dial the selected number.

Dialing a number by voice

Press the talk button to dial a number by voice, and say a name.

Answering a call

Press the talk button to answer a call when you hear incoming call tones.

Ending a call

Press the talk button to end a call.

Rejecting a call

Press and hold the talk button to reject a call when a call comes in.

Using options during a call

You can use the following functions to control your call during a call.

Muting the microphone

Press and hold the volume up/down buttons to turn the microphone off so that the person with whom you are speaking cannot hear you. Press and hold the volume up/down buttons again to turn the microphone back on.

Transferring a call from the phone to the headset

Press the talk button to transfer a call from the phone to the headset.

Placing a call on hold

Press and hold the talk button to place the current call on hold.

Answering a second call

Press the talk button to end the first call and answer a second call when you hear call waiting tones.

Press and hold the talk button to place the first call on hold and answer a second call when you hear waiting tones.

To switch between the current call and the held call, press and hold the talk button.

Appendix

Frequently asked questions

Will my headset work with laptops, PCs, and PDAs?	Your headset will work with devices that support your headset's Bluetooth version and profiles. For specifications, see page 17.
Will anything cause interference with my conversation when I am using my headset?	Appliances such as cordless phones and wireless networking equipment may cause interference with your conversation, usually adding a crackling noise. To reduce any interference, keep the headset away from other devices that use or produce radio waves.
Will my headset interfere with my car's electronics, radio, or computer?	Your headset produces significantly less power than a typical mobile phone. It also only emits signals that are in compliance with the international Bluetooth standard. Therefore, you should not expect any interference with standard consumer-grade electronics equipment.

Can other Bluetooth phone users hear my conversation?	When you pair your headset to your Bluetooth phone, you are creating a private link between only these two Bluetooth devices. The wireless Bluetooth technology used in your headset is not easily monitored by third parties because Bluetooth wireless signals are significantly lower in radio frequency power than those produced by a typical mobile phone.
The sound is echoing while talking.	Adjust the speaker volume, or move to another area and try again.
How do I take care of my headset?	Wipe it with a soft dry cloth.
The headset does not fully charge.	The headset and the charger may not have been connected properly. Separate the headset from the charger, reconnect, and charge the headset.

Certification and Safety approvals

FCC

FCC ID: A3LWEP650

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

The device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

Users are not permitted to make changes or modify the device in any way.

Changes or modifications not expressly approved by Samsung will void the user's authority to operate the equipment.

UL certified charger

The charger for this headset has met UL 1310 safety requirements. Please adhere to the following safety instructions per UL guide-lines.

FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS.

THIS POWER UNIT IS INTENDED TO BE CORRECTLY ORIENTATED IN A VERTICAL OR HORIZONTAL OR FLOOR MOUNT POSITION.

Warranty and parts replacement

Samsung warrants this product as free of defects in material, design and workmanship for the period of one year from the original date of purchase.(Depending on your country, the length of warranty may vary.)

If during the period of warranty this product proves defective under normal use and service you should return the product to the retailer from whom it was originally purchased or qualified service center. The liability of Samsung and its appointed maintenance company is limited to the cost of repair and/or replacement of the unit under warranty.

- The warranty is limited to the original purchaser
- A copy of your receipt or other proof of purchase is required for a proper warranty service
- The warranty is void if the serial number, date code label or product label is removed, or if the product has been subject to physical abuse, improper installation, modification, or repair by unauthorized third parties
- Specifically exempt from any warranty are limited-life consumable components such as batteries and other accessories
- Samsung will not assume any responsibility for any loss or damage incurred in shipping. All repair work on Samsung products by unauthorized third parties voids any warranty

Specifications

Item	Specifications and description
Bluetooth version	2.0+EDR
Support Profile	Headset Profile, Hands-Free Profile
Operating range	Up to 30 feet (10 meters)
Standby time	Up to 150 hours*
Talk time	Up to 6 hours*
Charging time	Approximately 2 hours*

* Depending on the phone type and usage, the actual time may vary.

