

COMBINATION LOCK INSTRUCTIONS

UNLOCK MODE:

TO UNLOCK, ALIGN PRESET (OR CURRENT) COMBINATION AND PULL PLUNGER OUTWARD UNTIL RIDGE IS SHOWN



CHANGING LOCK COMBINATION:

1. SET LOCK TO UNLOCK MODE (SEE ABOVE)
2. ON REVERSE SIDE, SPIN RIDGE DOWNWARD UNTIL IT STOPS
3. SET NEW COMBINATION

WARNING: BACKUP CODE NOT AVAILABLE IF COMBINATION IS FORGOTTEN OR LOST. USE CAUTION WHEN SETTING COMBINATION.

4. SPIN RIDGE BACK UPWARD UNTIL IT STOPS
5. PRESS PLUNGER INWARD TO SECURE LOCK



National Products, Inc., 8410 Dallas Ave S., Seattle, WA 98108, (206) 763-8361 www.ram-mount.com

RMR-INS-CODELOCK

COMBINATION LOCK INSTRUCTIONS

UNLOCK MODE:

TO UNLOCK, ALIGN PRESET (OR CURRENT) COMBINATION AND PULL PLUNGER OUTWARD UNTIL RIDGE IS SHOWN



CHANGING LOCK COMBINATION:

1. SET LOCK TO UNLOCK MODE (SEE ABOVE)
2. ON REVERSE SIDE, SPIN RIDGE DOWNWARD UNTIL IT STOPS
3. SET NEW COMBINATION

WARNING: BACKUP CODE NOT AVAILABLE IF COMBINATION IS FORGOTTEN OR LOST. USE CAUTION WHEN SETTING COMBINATION.

4. SPIN RIDGE BACK UPWARD UNTIL IT STOPS
5. PRESS PLUNGER INWARD TO SECURE LOCK



National Products, Inc., 8410 Dallas Ave S., Seattle, WA 98108, (206) 763-8361 www.ram-mount.com

RMR-INS-CODELOCK