


Includes:

- A. Light Unit
- B. Rechargeable LiPo Battery 1
- C. Action Camera Mount 2
- D. Cold shoe + Tripod Adaptor 3
- E. Mount Hardware (short)
- F. Mount Hardware (long)
- G. USB Extension Cord
- H. 2 x Anti-Vibration Pads 4



Notes: ¹Rechargeable LiPo battery already assembled into the Light Unit. ² Suitable for use with Go Pro Hero 2, Hero 2+, Hero 3 and Hero 3+ models or any action camera with a GoPro-style mount. ³ Cold shoe + Tripod Adaptor suitable for mounting onto a variety of Digital SLR models and can also be used for mounting directly to a tripod. ⁴ Anti-vibration pads of varying heights have been provided for optional use and assembly onto the Light Unit surface that is mounted closest to the Action Camera.

Before first use:

Please fully charge the battery before you use the [qudos] Action Light for the first time.

Removing the Battery:

Battery removal and insertion should be carried out in a clean, dustfree environment. Ensure your hands are clean. Should the area around the seal become dirty whilst handling, the seal will become compromised. Please refer to "waterproof seal care" section for further details and to ensure your product warranty is not voided.

1. Rotate tab, 2. Lift tab to release battery door, 3. Open battery door, 4. Remove battery from Light Unit.




Note: Repeat steps in reverse to replace battery in Light Unit.

Recharging the Battery:

- 1. Connect battery to USB Extension cord provided.
- **2.** Connect USB to a computer USB port or other electronic device with USB port.

A full charge cycle will take 5-6 hours. Battery charge status LED located at bottom of the battery.



Wall charger Specifications:

If using a wall charger, use an approved USB charger only. **AC input:** 90-260VAC 50/60Hz. **DC Output:** 5VDC (+0.25V/-0.1V) 2A. Use chargers with suitable approvals and certifications only. **Charging conditions:** Indoors only in temperatures above 10°C (50°F).

Mounting [qudos] Action Light:

There are a variety of mounting options and models that will enable you to capture images and video at night.








Scuba Diving applications:

Using the standard Action cam mount whilst scuba diving may produce undesirable 'backscatter'. For a more desirable result, use of a dedicated dive camera tray, placing the **[qudos]** Action light at least 30-50cm away from the Action Camera, is suggested.

Modes of use:

The On/Off switch is located on the top of the Light Unit. Press/hold for 2 seconds to turn it on and off. To switch between modes press the button for 1 second or less.




Target Spot Narrow 175 High / 100 Low 1.5 High / 3	on	Mode	Beam Angle	Lumens	Runtime (hrs)
<u>) </u>		Action	Wide	400 High / 225 Low	0.7 High / 1.3 Low
(W) Ambient Ultra wide 270 High / 70 Low 11 High / /	ф -	Target Spot	Narrow	175 High / 100 Low	1.5 High / 2.8 Low
Ambient Oitra wide 270 mign / 70 Edw 1.1 mign / 2	w,	Ambient	Ultra wide	270 High / 70 Low	1.1 High / 4.3 Low



Product Maintenance

Secure mounting:

Whichever way your light is being used, make sure to check that all mounting points are fastened tightly before use. Mount hardware parts have phillips head screwdriver details to assist you with tightening each fastener adequately.



Phillips head detail

Waterproof seal care:

If you're using your [qudos] Action Light in extreme sports like diving, downhill mountain-biking or in any environment that it's likely to become dirty or saturated, there are two things you must do regularly, if not after every use.



Washing the light


With the Light Unit battery door firmly closed, clean visible particles of debris from the body of the light with assistance of running water. If the light has stubborn stains, use a damp cloth.

Saltwater applications:

It is essential to rinse the light after use to reduce degradation caused by corrosion.

Checking and cleaning the seal area:

With the battery door open, check that all visible sealing surfaces are clear of dirt and debris. If dirt and debris are visible, remove and clean the seal, door and housing sealing surfaces with a clean/dry lint-free cloth.






Battery Storage:

When the light is not used for extended periods (more than fourteen daysv) users should implement Storage Mode. Use of this feature will optimise the life of the battery. After storage, recharge the battery to full before use.

- 1. Recharge the ACTION light until LED turns green
- 2. Replace battery into Light Unit and shut the door.
- 3. Turn the light on to any mode.
- 4. Hold the button for 5 seconds (until LED in the battery door alows red).

The light will drain to the optimum voltage level and turn itself off. This signals storage mode completion.



Warranty Terms

The [qudos] Action Light is guaranteed against manufacturing defects only. Damage from use, accident, misuse or normal wear and tear is not covered. Except for such repair or replacement, this product is without warranty, condition or other liability even though the defect or loss is caused by negligence or other fault. Knog assumes no liability for any accident, injury, death, loss, or other claim related to or resulting from the use of this product. In no event shall Knog be liable for incidental or consequential damages relating to or resulting from the use of this product or any of its parts. This product is not warrantied against waterhousing leakage or any resulting damage due to possible user error. Please follow the instructions carefully when sealing the Light Unit. 6 month battery warranty for manufacturing defects only. Return with original receipt to point of purchase two years from original date of purchase.

Warnings:

- Use only with approved USB Charging devices.
- Do not dispose of product in fire or expose to extreme heat.
- Do not attempt to disassemble product.
- Repeat storage mode procedure every 3 months of disuse to maintain battery longevity.
- Improper care and treatment of the light, it's sealing areas and mountings will void
- Not to be used for personal night vision or safety lighting. Designed specifically for providing illumination for video and photographic activities only.
- Clean with fresh water and mild soap; then rinse off. Warning: Strong detergent, alcohol and other harsh chemical may remove silkscreen logo.

Run time variations:

The [qudos] Action Light runtimes stated are based on tests carried out at room temperature. The light will operate best between OoC (32oF) and 40oC (104oF). Runtimes will vary depending on the external temperature. LiPo batteries have a chemistry that is vulnerable to environment and temperature, therefore runtimes will vary depending on these prevailing conditions.

Disclaimer and more information:

All information is correct at time of printing. Specifications are subject to change without notice. Please visit www.knog.com.au for more information and updates.