



www.isound.net

Power View Pro



User's Guide



Power View Pro

Package Contents:

- POWER VIEW PRO
- 110/240 Volt AC adapter
- iPod/iPhone Brackets (see below for specifics)
- User's Guide/Warranty Card
- Registration Card

Included Brackets (compatible models):

- iPhone 4 (16GB/32GB)
- iPhone 3GS (8GB/16GB/32GB)
- iPhone 3G (6GB/16GB)
- iPod touch (3rd Gen – 32GB/64GB)
- iPod nano (5th Gen – 8GB/16GB)

NOTE: *The iPad charging well is not removable.*

Product Set-UP:

- 1** Connect the included 110/240 Volt AC adapter to the DC input located on the back of the POWER VIEW PRO. Connect the other end to any powered standard wall outlet.
- 2** The POWER VIEW PRO includes iPod/iPhone brackets for some of the latest iPod/iPhone models. (Please see above for which specific models have included adapters)
- 3** To connect the iPod/iPhone to the right side of the POWER VIEW PRO, choose the corresponding bracket and place it on the charging well of the POWER VIEW PRO.

- 4 Place the iPod/iPhone onto the charging pin. Charging will begin automatically.

NOTE: Please refer to your original User's Guide of your iPod/iPhone for charging times. Charge status can be viewed on the device being charged.

- 5 To connect the iPad to the left side of the POWER VIEW PRO, place it onto the charging pin. Charging will begin automatically.

NOTE: Please refer to your original User's Guide of your iPad for charging times. Charge status can be viewed on the device being charged.

iPad Viewing Dock:

To display the iPad horizontally, place the iPad onto the display dock located on the front of the POWER VIEW PRO. To charge the iPad while viewing on the display dock, connect your original iPad charging cable to the bottom of the iPad. Connect the other end to one of the USB ports located on the back of the POWER VIEW PRO.

NOTE: An iPad and One (1) iPod or iPhone can be charged simultaneously. There are also 2 USB ports included on the back of the POWER VIEW PRO that can charge other USB powered devices. Please refer to your original User's Guide of the USB powered device for charging times.



WARRANTY CARD

All dreamGEAR/i.Sound products come with a limited warranty and have been subjected to a thorough series of tests to ensure the highest level of dependability and compatibility. It is unlikely that you will experience any problem, but if a defect should become apparent during the use of this product, dreamGEAR warrants to the original consumer purchaser that this product will be free from defects in material and workmanship for a period of 120 days from the date of your original purchase. If a defect covered by this warranty occurs, dreamGEAR, at its option, will repair or replace the product purchased at no charge. If a replacement is necessary and your product is no longer available, a comparable product may be substituted at the sole discretion of dreamGEAR.

This warranty does not cover normal wear and tear, abusive use or misuse, modification, tampering or by any other cause not related to either materials or workmanship. This warranty does not apply to products used for any industrial, professional or commercial purposes.

For service on any defective product under the 120-day warranty policy, please contact
Consumer Support
to obtain a Return Authorization Number.

NOTE: *dreamGEAR will not process any defective claims without a Return Authorization Number.*

Consumer Support Hotline:
877-999-DREAM (3732) (U.S. and Canada only) or
310-222-1045 (International)

Consumer Support Email: support@dreamgear.net

Websites:
www.dreamgear.net
www.isound.net